

# OPERATING INSTRUCTIONS




**Design &  
Manufacturing Ltd.**

**SERIES 58320 ULTRALIGHT BIRD**




## INSTALLATION

1. Feed the line to be blown through the duct seal device.



2. Attach the line to the eye on the rear of the bird. Insert the bird into the duct.



3. Install the duct seal device in the end of the duct and begin blowing.

## SAFETY



1. Never use a worn, defective or incomplete component. Ensure that all components of the system are able to withstand the maximum system pressures. Components not rated for the system pressure may fail and release the stored energy.
2. Be prepared for the unexpected. Use recognized safety practices and wear recognized safety equipment.

## SERVICE



1. There are no service or maintenance procedures for this product.